

# HUNTONIT PRO WALL

851 1224

## Woodfiber wall panel for a smooth interior wall



ASTMA- OG  
ALLERGI FORBUNDET  
*— giver Nørges Trusker*

member of

**BYGMA**  
group

# HUNTONIT PRO WALL

## Woodfiber board for interior walls

The world's first wooden fiberboard wall panel that provides a smooth wall in record time. Perfect whether you're building new or renovating. The panel is 11 mm thick and is available in various lengths.

The wall panel from Huntonit provides high-quality walls that can be installed immediately. Say goodbye to drywall, spackling, and sanding large areas. PRO WALL is primed and ready for wallpaper or paint with your favorite color.

PRO WALL is very stabile and has excellent resistance to axial withdrawal of screws, meaning you can attach bookshelves and heavier items directly to the wall.

Available in:  
2420 mm, 2500 mm, 2800 mm and 3050 mm.  
11 mm thick and 620 mm wide.

PRO WALL captures

12 kg CO<sub>2</sub>  
pr kvm



### A smooth woodpanel

Wood, water, and a small dosage of hydrophobing agents, makes Huntonit PRO WALL more resistant to moisture and temperature fluctuations than other wood panels.

By using wood, we create a more pleasant indoor climate which will contribute to increased well-being.

PRO WALL is recommended by the Norwegian Asthma and Allergy Association.

Properties for Huntonit PRO WALL are declared in Nordic Ecolabelling's Supply Chain Declaration Portal.

PRO WALL has a fire rating of D-s1,d0 and a sound-absorbing effect. The boards have a technical approval from SINTEF and can be used in REI30 and REI60 constructions.


Read more about PRO WALL at [www.huntonit.com](http://www.huntonit.com).

### Norwegian product

By choosing PRO WALL you will enjoy these advantages:

- A wooden product
- Quick and easy installation
- Raw material extracted from Nordic forests
- Recommended by NAAF\*
- Good screw retention
- Locally produced in Norway
- Without adhesives
- Climate class 2

Solid and secure click lock



How to install

# HUNTONIT PRO WALL



TOOLS  
NEEDED  
FOR  
INSTALLATION.

**1**

MAKE  
SURE ALL  
WALLS ARE  
STRAIGHT  
AND LEVEL.



**2**

RAISE THE BOARDS  
5MM TO 10MM UP  
FROM THE FLOOR.




**4**

200MM BETWEEN  
FIXINGS ON VERTICAL  
BATTEN. USE SCREWS  
OR BRADS.



**3** START ASSEMBLY FROM LEFT TO RIGHT. ADD HORIZONTAL  
BATTENS IN CORNERS AND AT DOORS/WINDOWS.




**5**

DOUBLE  
FIXING ON  
EACH  
HORIZONTAL  
BATTEN.



**6**

USE A 1MM STRING OF  
WOOD GLUE ALONG  
THE JOINT PROFILE.  
EACH PANEL MUST BE  
COMPLETELY FIXED  
TOP, BOTTOM AND  
SIDES BEFORE NEXT  
PANEL IS MOUNTED.




**7**

USE THE ASSOCIATED  
IMPACT BLOCK TO  
MAKE THE JOINT  
COMPLETELY TIGHT.



**8**

AFTER EACH BOARD  
IS FITTED, SAND  
LIGHTLY (120 GRADE  
PAPER) OVER THE  
JOINT BEFORE  
ADDING PAINTING  
OR WALL PAPERING.



**9**

THE WALL CAN BE  
FITTED WITHOUT  
INTERNAL CORNER  
PROFILE. FOR  
EXTERNAL CORNERS,  
USE OUR FLEXILIST.



**10**

ACRYLIC FILLER IS  
RECOMMENDED FOR  
INTERNAL CORNERS.



## HUNTONIT

Huntonit AS  
Postboks 21, 4701 Vennesla, Norway  
Tlf.: +47 38 13 71 00  
e-post: byggma@byggma.no  
www.huntonit.com